



# RG60/72/84 CRG48/60

## ROAD GRADER

Published 08/22

Part No. 50069588


## OPERATOR'S MANUAL



This Operator's Manual is an integral part of the safe operation of this machine and must be maintained with the unit at all times. **READ, UNDERSTAND, and FOLLOW** the Safety and Operation Instructions contained in this manual before operating the equipment. C01-Cover str



FC-BL-0006



FC-BL-0007

**BUSH HOG®**

2501 Griffin Ave.  
Selma, AL 36703  
334-874-2700  
[www.bushhog.com](http://www.bushhog.com)

Bush Hog Web Page



[www.algqr.com/bwe](http://www.algqr.com/bwe)

**¡ATENCIÓN!**  
LEA EL INSTRUCTIVO



Si No Lee Ingles, Pida  
Ayuda a Alguien  
Que Se Lo Lea Para Que le  
Traduzca Las  
Medidas de Seguridad

**MEMBER OF THE  
ALAMO GROUP**  
ALWAYS ON THE CUTTING EDGE®

©2022 Alamo Group Inc.




# To the Owner/Operator/Dealer

All implements with moving parts are potentially hazardous. There is no substitute for a cautious, safe-minded operator who recognizes the potential hazards and follows reasonable safety practices. The manufacturer has designed this implement to be used with all its safety equipment properly attached to minimize the chance of accidents.

**BEFORE YOU START!** Read the safety messages on the implement and shown in your manual. Observe the rules of safety and common sense!

For future reference, record your Bush Hog product model number and serial number.

|        |  |                |  |               |  |
|--------|--|----------------|--|---------------|--|
| Dealer |  | Telephone      |  | Model Number  |  |
| Owner  |  | Purchase Date: |  | Serial Number |  |



## WARRANTY INFORMATION:

Read and understand the complete Warranty Statement found in this Manual. Fill out the Warranty Registration Form in full and return it to within 30 Days. Make certain the Serial Number of the Machine is recorded on the Warranty Card and on the Warranty Form that you retain.



# Table of Contents

|  |              |
|--|--------------|
| <b>SAFETY SECTION .....</b>                      | <b>1 - 1</b> |
| GENERAL SAFETY INSTRUCTIONS AND PRACTICES .....  | 1 - 2        |
| PARTS INFORMATION .....                          | 1 - 8        |
| DECAL LOCATION .....                             | 1 - 9        |
| DECAL DESCRIPTION .....                          | 1 - 10       |
| FEDERAL LAWS AND REGULATIONS .....               | 1 - 11       |
| <b>INTRODUCTION SECTION .....</b>                | <b>2 - 1</b> |
| ATTENTION OWNER/OPERATOR .....                   | 2 - 4        |
| BUSH HOG LIMITED WARRANTY .....                  | 2 - 5        |
| <b>ASSEMBLY SECTION.....</b>                     | <b>3 - 1</b> |
| DEALER SET-UP INSTRUCTIONS .....                 | 3 - 2        |
| <b>OPERATION SECTION .....</b>                   | <b>4 - 1</b> |
| STANDARD EQUIPMENT AND SPECIFICATIONS .....      | 4 - 3        |
| OPERATOR REQUIREMENTS .....                      | 4 - 4        |
| TRACTOR REQUIREMENTS .....                       | 4 - 5        |
| ROPS and Seat Belt.....                          | 4 - 5        |
| Tractor Horsepower.....                          | 4 - 5        |
| Tractor 3-Point Hitch - RG Models .....          | 4 - 6        |
| Tractor 3-Point Hitch - CRG Models .....         | 4 - 7        |
| Front End Weight.....                            | 4 - 7        |
| GETTING ON AND OFF THE TRACTOR .....             | 4 - 7        |
| Boarding the Tractor.....                        | 4 - 8        |
| Dismounting the Tractor .....                    | 4 - 8        |
| STARTING THE TRACTOR .....                       | 4 - 9        |
| CONNECTING THE IMPLEMENT TO THE TRACTOR .....    | 4 - 9        |
| Connecting the Road Grader.....                  | 4 - 10       |
| PRE-OPERATION INSPECTION AND SERVICE .....       | 4 - 11       |
| Tractor Pre-Operation Inspection/Service .....   | 4 - 11       |
| Blade Pre-Operation Inspection/Service .....     | 4 - 12       |
| BLADE & BOX BLADE PRE-OPERATION INSPECTION ..... | 4 - 13       |
| TRACTOR PRE-OPERATION INSPECTION .....           | 4 - 14       |
| DRIVING THE TRACTOR AND IMPLEMENT .....          | 4 - 15       |
| Starting the Tractor.....                        | 4 - 16       |
| Brake and Differential Lock Setting .....        | 4 - 16       |
| Driving the Tractor and Implement .....          | 4 - 16       |
| Operating the Tractor and Implement.....         | 4 - 17       |
| Operating the Grader.....                        | 4 - 17       |
| Backfilling and Snow Removal .....               | 4 - 17       |
| SHUTTING DOWN THE IMPLEMENT .....                | 4 - 17       |
| DISCONNECTING THE BLADE FROM THE TRACTOR.....    | 4 - 18       |
| ROAD GRADER AND STORAGE .....                    | 4 - 18       |
| TRANSPORTING THE TRACTOR AND IMPLEMENT .....     | 4 - 18       |



# Table of Contents

DRIVING THE TRACTOR AND IMPLEMENT ..... 4 - 18

    Transporting on Public Roadways ..... 4 - 20

    Hauling the Tractor and Implement ..... 4 - 22

TROUBLESHOOTING GUIDE ..... 4 - 23

**MAINTENANCE SECTION .....5 - 1**

REPLACING SCARIFIER POINTS - (RG Models Only)..... 5 - 2

PROPER TORQUE FOR FASTENERS ..... 5 - 2



# SAFETY SECTION

Safety Section 1-1



# SAFETY

## GENERAL SAFETY INSTRUCTIONS AND PRACTICES

A careful operator is the best operator. Safety is of primary importance to the manufacturer and should be to the owner/operator. Most accidents can be avoided by being aware of your equipment, your surroundings, and observing certain precautions. The first section of this manual includes a list of Safety Messages that, if followed, will help protect the operator and bystanders from injury or death. Read and understand these Safety Messages before assembling, operating or servicing this Implement. This equipment should only be operated by those persons who have read the manual, who are responsible and trained, and who know how to do so responsibly.



The Safety Alert Symbol combined with a Signal Word, as seen below, is used throughout this manual and on decals which are attached to the equipment. The Safety Alert Symbol means: "ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!" The Symbol and Signal Word are intended to warn the owner/operator of impending hazards and the degree of possible injury faced when operating this equipment.

**Practice all usual and customary safe working precautions and above all---remember safety is up to YOU. Only YOU can prevent serious injury or death from unsafe practices.**



Indicates an imminently hazardous situation that, if not avoided, WILL result in DEATH OR VERY SERIOUS INJURY.



Indicates an imminently hazardous situation that, if not avoided, COULD result in DEATH OR SERIOUS INJURY.



Indicates an imminently hazardous situation that, if not avoided, MAY result in MINOR INJURY.



Identifies special instructions or procedures that, if not strictly observed, could result in damage to, or destruction of the machine, attachments or the environment.

**NOTE:** *Identifies points of particular interest for more efficient and convenient operation or repair.* (SG-1) str

READ, UNDERSTAND, and FOLLOW the following Safety Messages. Death or serious injury may occur unless care is taken to follow the warnings and instructions stated in the Safety Messages. Always use good common sense to avoid hazards. (SG-2) str



Si no lee ingles, pida ayuda a alguien que si lo lea para que le traduzca las medidas de seguridad. (SG-3) str

**¡ LEA EL INSTRUCTIVO!**





# SAFETY

## DANGER

Never operate the Tractor or Implement until you have read and completely understand this Manual, the Tractor Operator's Manual, and each of the Safety Messages found in the Manual or on the Tractor and Implement. Learn how to stop the tractor engine suddenly in an emergency. Never allow inexperienced or untrained personnel to operate the Tractor or Implement without supervision. Make sure the operator has fully read and understood the manuals prior to operation.

(SG-4)str




## WARNING

Always maintain the safety signs in good readable condition. If the safety signs are missing, damaged, or unreadable, obtain and install replacement safety signs immediately. (SG-5)str

## WARNING

Make certain that the "Slow Moving Vehicle" (SMV) sign is installed in such a way as to be clearly visible and legible. When transporting the Equipment use the Tractor flashing warning lights and follow all local traffic regulations. (SG-6)str



## WARNING

Operate this Equipment only with a Tractor equipped with an approved roll-over-protective system (ROPS). Always wear seat belts. Death or serious injury could result from falling off the tractor, particularly during a turnover when the operator could be pinned under the ROPS. (SG-7) str




## WARNING

Do not modify or alter this Implement. Do not permit anyone to modify or alter this Implement, any of its components or any Implement function. (SG-8)str

## DANGER

BEFORE leaving the tractor seat lower the implement, set the parking brake and/or set the tractor transmission in parking gear, disengage the PTO, stop the engine, remove the key, and wait for all moving parts to stop. Place the tractor shift lever into a low range or parking gear to prevent the tractor from rolling. Never dismount a Tractor that is moving or while the engine is running. Operate the Tractor controls from the tractor seat only.

(SG-9)str



## DANGER

Never allow children or other persons to ride on the Tractor or Implement. Falling off can result in death or serious injury. (SG-10)str





# SAFETY

## SAFETY

### **DANGER**

Never allow children to operate, ride on, or come close to the Tractor or Implement. Usually, 16-17 year-old children who are mature and responsible can operate the implement with adult supervision, if they have read and understand the Operator's Manuals, been trained in proper operation of the tractor and Implement, and are physically large enough to reach and operate the controls easily. (SG-11) str



### **WARNING**

Do not mount or dismount the Tractor while the tractor is moving. Mount the Tractor only when the Tractor and all moving parts are completely stopped. Dismounting a moving power unit can result in a crushing hazard that can cause death or serious injury. (SG-12) str



### **DANGER**

Start tractor only when properly seated in the Tractor seat. Starting a tractor in gear can result in death or serious injury. Read the Tractor operators manual for proper starting instructions. (SG-13) str



### **DANGER**

Never work under the Implement, the framework, or any lifted component unless the Implement is securely supported or blocked up to prevent sudden or inadvertent falling which could cause death or serious injury. (SG-14)str




### **WARNING**

Do not operate this Equipment with hydraulic oil or fuel leaking. Oil and fuel are explosive and their presence could present a hazard. Do not check for leaks with your hand! High-pressure oil streams from breaks in the line could penetrate the skin and cause tissue damage including gangrene. To check for a hose leak, SHUT the unit ENGINE OFF and remove all hydraulic pressure. Wear oil impenetrable gloves, safety glasses and use cardboard to check for evidence of oil leaks. If you suspect a leak, REMOVE the HOSE and have it tested at a Dealer. If oil does penetrate the skin, have the injury treated immediately by a physician knowledgeable and skilled in this procedure. (SG-15) str



### **WARNING**

The operator and all support personnel should wear hard hats, safety shoes, safety glasses, and proper hearing protection at all times for protection from injury including injury from items that may be thrown by the equipment. (SG-16)str





# SAFETY

## CAUTION

PROLONGED EXPOSURE TO LOUD NOISE MAY CAUSE PERMANENT HEARING LOSS! Tractors with or without an Implement attached can often be noisy enough to cause permanent hearing loss. We recommend that you always wear hearing protection if the noise in the Operator's position exceeds 80db. Noise over 85db over an extended period of time will cause severe hearing loss. Noise over 90db adjacent to the Operator over an extended period of time will cause permanent or total hearing loss. **NOTE:** *Hearing loss from loud noise [from tractors, chain saws, radios, and other such sources close to the ear] is cumulative over a lifetime without hope of natural recovery.* (SG-17)str



## WARNING

Transport only at speeds where you can maintain control of the equipment. Serious accidents and injuries can result from operating this equipment at high speeds. Understand the Tractor and Implement and how it handles before transporting on streets and highways. Make sure the Tractor steering and brakes are in good condition and operate properly.



Before transporting the Tractor and Implement, determine the proper transport speeds for you and the equipment. Make sure you abide by the following rules:

Test the tractor at a slow speed and increase the speed slowly. Apply the Brakes smoothly to determine the stopping characteristics of the Tractor and Implement. As you increase the speed of the Tractor the stopping distance increases. Determine the maximum transport speed not to exceed 20 mph (30 kph) for transporting this equipment.

Test the equipment at a slow speed in turns. Increase the speed through the turn only after you determine that the equipment can be operated at a higher speed. Use extreme care and reduce your speed when turning sharply to prevent the tractor and implement from turning over. Determine the maximum turning speed for you and this equipment before operating on roads or uneven ground.

Only transport the Tractor and Implement at the speeds which allow you to properly control the equipment.

Be aware of the operating conditions. Do not operate the Tractor with weak or faulty brakes or worn tires. When operating down a hill or on wet or rain slick roads, the braking distance increases: use extreme care and reduce your speed. When operating in traffic always use the Tractor's flashing warning lights and reduce your speed. Be aware of traffic around you and watch out for the other guy. (SG-19)str



## WARNING

Never attempt to lubricate, adjust, or remove material from the Implement while it is in motion or while tractor engine is running. (SG-20)str

SAFETY




# SAFETY

## SAFETY

### **WARNING**

Periodically inspect all moving parts for wear and replace when necessary with authorized service parts. Look for loose fasteners, worn or broken parts, and leaky or loose fittings. Make sure all pins have cotter pins and washers. Serious injury may occur from not maintaining this machine in good working order. (SG-21) str



### **WARNING**

Always read carefully and comply fully with the manufacturer's instructions when handling oil, solvents, cleansers, and any other chemical agent. (SG-22) str



### **DANGER**

Never run the Tractor engine in a closed building or without adequate ventilation. The exhaust fumes can be hazardous to your health. (SG-23) str

### **DANGER**

KEEP AWAY FROM ROTATING ELEMENTS to prevent entanglement and possible death or serious injury. (SG-24) str



### **DANGER**

Never allow children to play on or around Tractor or Implement. Children can slip or fall off the Equipment and be killed or injured. Inadvertent contact with controls can cause the Implement to shift or fall crushing themselves or others. (SG-25) str

### **DANGER**

DO NOT use drugs or alcohol immediately before or while operating the Tractor and Implement. Drugs and alcohol will affect an operator's alertness and coordination and therefore affect the operator's ability to operate the equipment safely. Before operating the Tractor or Implement, an operator on prescription or over-the-counter medication must consult a medical professional regarding any side effects of the medication that would hinder their ability to operate the Equipment safely. NEVER knowingly allow anyone to operate this equipment when their alertness or coordination is impaired. Serious injury or death to the operator or others could result if the operator is under the influence of drugs or alcohol. (SG-27) str





# SAFETY

## DANGER

Operate the Tractor and/or Implement controls only while properly seated in the Tractor seat with the seat belt securely fastened around you. Inadvertent movement of the Tractor or Implement may cause death or serious injury. (SG-29)str

## WARNING

Be particularly careful when transporting the Implement with the Tractor. Turn curves or go up hills only at a low speed and using a gradual steering angle. Rear mounted implements move the center of gravity to the rear and remove weight from the front wheels. Make certain, by adding front ballast, that at least 20% of the tractor's weight is on the front wheels to prevent rearing up, loss of steering control or Tractor tip-over. Slow down on rough or uneven surfaces to prevent loss of steering control which could result in property damage or possible injury. Do not transport unless 3-Point lift lever is fully raised and in the latched transport position. Dropping implement in transport can cause serious damage to the tractor and/or Implement and possibly cause the operator or others to be killed or injured. (S3PT-02)str

## WARNING

Relieve hydraulic pressure prior to doing any maintenance or repair work on the Implement. Place the Implement on the ground or securely blocked up, disengage the PTO, and turn off the tractor engine. Push and pull the Remote Cylinder lever in and out several times prior to starting any maintenance or repair work. (S3PT-09)str



## DANGER

This Implement may be wider than the Tractor. Be careful when operating or transporting this equipment to prevent the Implement from running into or striking sign posts, guard rails, concrete abutments or other solid objects. Such an impact could cause the Implement and Tractor to pivot violently resulting in loss of steering control, death, or serious injury. Never allow the Implement to contact obstacles. (S3PT-12)str

## DANGER

There are obvious and hidden potential hazards in operating Rear Blades and Box Scrapers as in all power-driven equipment. REMEMBER! This machine is often operated in rough terrain conditions that include gullies, holes, slopes, hidden obstructions and the like. Death or serious injury may occur unless care is taken to assure the personal safety of the operator and bystanders in the area. (SBL-1)str

## DANGER

NEVER PARK BLADE ON THE BACK OF THE MOLDBOARD. Inadvertent falling could cause death or serious injury. ALWAYS LOWER HITCH onto stand or onto secure blocks. (SBL-2)str

## DANGER

Never leave blade unattended in the lifted position. Accidental operation of lifting lever or a hydraulic failure may cause sudden drop of unit with subsequent death or injury by crushing. Lower Stand and pin in place, or put a secure support under the A-Frame. Lower Blade carefully to the ground. Do not put hands or feet under lifted components. (SBL-4)str

## WARNING

Cancer and Reproductive Harm [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



# SAFETY

## **PARTS INFORMATION**

Bush Hog products are designed utilizing specifically matched system components to ensure optimum equipment performance. These parts are made and tested to Bush Hog specifications. Non-genuine "will fit" parts do not consistently meet these specifications. The use of "will fit" parts may reduce equipment performance, void warranties, and present a safety hazard. Use genuine Bush Hog parts for economy and safety. (SPBH-2)str

### **SEE YOUR BUSH HOG DEALER**

Operator's & Parts Manuals



[www.algqr.com/bpm](http://www.algqr.com/bpm)

In addition to the design and configuration of this Implement, including Safety Signs and Safety Equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence, and proper training of personnel involved in the operation, transport, maintenance, and storage of the machine. Refer also to Safety Messages and operation instruction in each of the appropriate sections of the Tractor and Equipment Manuals. Pay close attention to the Safety Signs affixed to the Tractor and Equipment. (SG-18)str


SAFETY



# SAFETY

## DECAL LOCATION

**NOTE:** Bush Hog supplies safety decals on this product to promote safe operation. Damage to the decals may occur while in shipping, use, or reconditioning. Bush Hog cares about the safety of its customers, operators, and bystanders, and will replace the safety decals on this product in the field, free of charge (Some shipping and handling charges may apply). Contact your Bush Hog dealer to order replacement decals.



DL-BL-0012

| ITEM | PART NO. | QTY | TYPE       | DESCRIPTION                |
|------|----------|-----|------------|----------------------------|
| 1.   | 50057097 | 1   | CAUTION    | Read Operator's Manual     |
| 2.   | 90960BH  | 1   | WARNING    | Blade Adjustment           |
| 3.   | 00725746 | 1   | PELIGRO    | Spanish Translation        |
| 4.   | 50031213 | 2   | REFLECT    | Red Reflector              |
| 5.   | 50031212 | 2   | REFLECT    | Amber Reflector            |
| 6.   | NFS      | 1   | SERIAL PLT | Serial Number Plate        |
| 7.   | 50069585 | 2   | LOGO       | Model RG60                 |
|      | 50069586 | 2   | LOGO       | Model RG72                 |
|      | 50069587 | 2   | LOGO       | Model RG84                 |
|      | 50071420 | 2   | LOGO       | Model CRG48                |
|      | 50071527 | 2   | LOGO       | Model CRG60                |
| 8.   | 50058089 | 2   | LOGO       | Bush Hog                   |
| 9.   | 50069588 | 1   | ---        | Operator's Manual          |
| 10.  | NFS      | 1*  | REFLECT    | SMV Sign                   |
| 11.  | D960     | 1   | WARNING    | Proposition 65 (not shown) |

\* Supplied by Tractor Manufacturer



# SAFETY

## DECAL DESCRIPTION

SAFETY

**WARNING**



**TO AVOID SERIOUS INJURY OR DEATH:**

**1. DURING RAKE ADJUSTMENTS:**

- \*AVOID RAKE SWING DOWNHILL WHEN INDEX PINS ARE REMOVED; PLACE TRACTOR ON LEVEL GROUND.
- \*KEEP FINGERS AWAY FROM ADJUSTING HOLES.
- \*KEEP BODY, HANDS AND FEET CLEAR FROM ELEVATED RAKE AND MOVING PARTS.


**2. DURING RAKE OPERATION:**




- \*AVOID HIGH SPEED OVER ROUGH TERRAIN OR SLOPES.

90960BH

**WARNING**

**Cancer and Reproductive Harm**  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov) D960

**CAUTION**



**TO AVOID SERIOUS INJURY OR DEATH:**


- READ OPERATORS MANUAL BEFORE OPERATING AND FOLLOW ALL PRECAUTIONS (CONTACT DEALER FOR MANUAL).
- IT IS RECOMMENDED OPERATOR USE ROLLOVER PROTECTIVE SYSTEM AND SEAT BELT EQUIPPED TRACTOR FOR ALL IMPLEMENT OPERATIONS.
- ADD TRACTOR FRONT END WEIGHTS REQUIRED FOR TRACTOR STABILITY.
- LOWER IMPLEMENT TO GROUND, STOP ENGINE, PLACE TRANSMISSION IN NEUTRAL OR PARK, SET PARKING BRAKE AND REMOVE KEY BEFORE DISMOUNTING TRACTOR OR ADJUSTING IMPLEMENT.
- ALLOW NO RIDERS.
- TRANSPORT BLADE IN FULL RAISED POSITION WITH TILT AND OFFSET ANGLES AT "ZERO" POSITION.

50057097

**PELIGRO**

LEA EL INSTRUCTIVO

Si No Lee Ingles, Pida Ayuda a Alguien Que Si Lo Lea Para Que le Traduzca las Medidas de Seguridad.



00725746



# SAFETY

## **FEDERAL LAWS AND REGULATIONS**

This section is intended to explain in broad terms the concept and effect of federal laws and regulations concerning employer and employee equipment operators. This section is not intended as a legal interpretation of the law and should not be considered as such.

### **Employer-Employee Operator Regulations**

U.S. Public Law 91-596 (The Williams-Steiger Occupational and Health Act of 1970) OSHA

#### **This Act Seeks:**

"...to assure so far as possible every working man and woman in the nation safe and healthful working conditions and to preserve our human resources..."

#### **DUTIES**

Sec. 5 (a) Each employer-

(1) shall furnish to each of his employees employment and a place of employment which are free from recognized hazards that are causing or are likely to cause death or serious physical harm to his employees;

(2) shall comply with occupational safety and health standards promulgated under this Act.

(b) Each employee shall comply with occupational safety and health standards and all rules, regulations and orders issued pursuant to this Act which are applicable to his own actions and conduct.

### **OSHA Training Requirements**

***Title 29, Code of Federal Regulations Part 1928.57(a)(6).*** [www.osha.gov](http://www.osha.gov)

Operator instructions. At the time of initial assignment and at least annually thereafter, the employer shall instruct every employee who operates an agricultural tractor and implements in the safe operating practices and servicing of equipment with which they are or will be involved, and of any other practices dictated by the work environment.

Keep all guards in place when the machine is in operation;

Permit no riders on equipment

Stop engine, disconnect the power source, and wait for all machine movement to stop before servicing, adjusting, cleaning or unclogging the equipment, except where the machine must be running to be properly serviced or maintained, in which case the employer shall instruct employees as to all steps and procedures which are necessary to safely service or maintain the equipment.

Make sure everyone is clear of machinery before starting the engine, engaging power, or operating the machine.

### **Employer Responsibilities:**

To ensure employee safety during Tractor and Implement operation, it is the employer's responsibility to:

1. Train the employee in the proper and safe operation of the Tractor and Implement.
2. Require that the employee read and fully understand the Tractor and Implement Operator's Manual.
3. Permit only qualified and properly trained employees to operate the Tractor and Implement.
4. Maintain the Tractor and Implement in a safe operational condition and maintain all shields and guards on the equipment.
5. Ensure the Tractor is equipped with a functional ROPS and seat belt and require that the employee operator securely fasten the safety belt and operate with the ROPS in the raised position at all times.
6. Forbid the employee operator to carry additional riders on the Tractor or Implement.
7. Provide the required tools to maintain the Tractor and Implement in a good safe working condition and provide the necessary support devices to secure the equipment safely while performing repairs and service.
8. Require that the employee operator stop operation if bystanders or passersby come within 300 feet.

### **Child Labor Under 16 Years of Age**

Some regulations specify that no one under the age of 16 may operate power machinery. It is your responsibility to know what these regulations are in your own area or situation. (Refer to U.S. Dept. of Labor, Employment Standard Administration, Wage & Home Division, Child Labor Bulletin #102.)







# INTRODUCTION SECTION

Introduction Section 2-1



# INTRODUCTION

## INTRODUCTION

This Grader Blade is designed with care and built with quality materials by skilled workers. Proper assembly, maintenance, and operating practices, as described in this manual, will help the owner/operator get years of satisfactory service from the machine.

The purpose of this manual is to familiarize and instruct. The Assembly Section instructs the owner/operator in the correct assembly of the Blade using standard and optional equipment.

Careful use and timely service saves extensive repairs and costly downtime losses. The Operation and Maintenance Sections of the manual train the owner/operator how to work the Blade correctly and attend to appropriate maintenance. The Trouble Shooting Guide helps diagnose difficulties and offers solution to the problems.

Safety is of primary importance to the owner/operator and to the manufacturer. The first section of this manual includes a list of Safety Messages, that, if followed, will help protect the operator and bystanders from injury or death. Many of the Safety Messages will be repeated throughout the manual. The owner/operator/dealer should know these Safety Messages before assembly and be aware of the hazards of operating this blade during assembly, use, and maintenance. The Safety Alert Symbol combined with a Signal Word, as seen below, is intended to warn the owner/operator of impending hazards and the degree of possible injury faced when operating this machine.



Indicates a hazardous situation that, if not avoided, WILL result in DEATH OR VERY SERIOUS INJURY.



Indicates a hazardous situation that, if not avoided, COULD result in DEATH OR SERIOUS INJURY.



Indicates a hazardous situation that, if not avoided, MAY result in MINOR OR MODERATE INJURY.



Identifies special instructions or procedures that, if not strictly observed, could result in damage to, or destruction of the machine, attachments or the environment.




# INTRODUCTION

## INTRODUCTION



FC-BL-0006



FC-BL-0007

**NOTE:** All references made in this manual to right, left, front, rear, top or bottom are as viewed facing the direction of forward travel with implement properly attached to tractor.

These Grader Blades fit a wide range of tractors. The Heavy-Duty, CAT I three-point hitch, 4" x 4" mainframe and double-lug lower hitch points help ensure performance and reliability. Shearing action of the material being worked is provided by two, reversible, high carbon steel cutting edges. One edge mounted inside the box and the other mounted on the back side allow the blade to be operated in forward or reverse. Maximum penetration in hard-packed material is accomplished by the scarifier kit which has a maximum working depth of 3".

Carefully read the Operator's Manual completely, understand the Safety Messages and instructions, and know how to operate correctly both the tractor and Blade.

Literature Page



[www.algqr.com/ble](http://www.algqr.com/ble)



# INTRODUCTION

## **ATTENTION OWNER/OPERATOR**

BEFORE OPERATING THIS MACHINE:

1. Carefully read the Operator's Manual, completely understand the Safety Messages and instructions, and know how to operate correctly both the tractor and blade.
2. Fill out the Warranty card in full. Be sure to answer all questions, including the Serial Number on the implement. Mail within 30 days of delivery date of this implement.

**NOTE:** Warranties are honored only if completed "Owner Registration and Warranty" forms are received by Bush Hog within thirty days of delivery of the implement.

3. Record the Model and Serial Numbers on the following Warranty Page and at the front of the Operator's Manual. Keep this as part of the permanent maintenance file for the Implement.

**WARNING**

**TO AVOID DEATH OR SERIOUS INJURY:**

- ONLY use genuine Bush Hog replacement parts, which have been validated and tested to use on Bush Hog equipment by the manufacturer.
- The equipment manufacturer cannot verify the material or structural integrity of third-party supplied non-genuine replacement parts.
- Using non-genuine parts can result in the part failing, creating hazardous conditions for operator and bystanders.

Contact local dealer or Bush Hog about repair parts at:  
2501 Griffin Ave., Selma, AL 36701  
Customer Service: 800-363-6096.  
Email: [contactus@bushhog.com](mailto:contactus@bushhog.com) [www.algqr.com/bpm](http://www.algqr.com/bpm)



**WARNING**  
Cancer and Reproductive Harm  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

**IMPORTANT**

**BE AWARE**  
**BE ALERT**  
**BE ALIVE**

**BE TRAINED**  
**Before Operating this Mower**



To prevent serious injury to yourself and/or bystanders, be trained in Safe Mowing Practices. Alamo Group Companies as well as AEM and FEMA provide training material that is critical for your Safety and the Safety of others when operating this equipment. Make these Safety Procedures an important part of every workday. Read and understand the Operator's Manual. [www.algqr.com/bve](http://www.algqr.com/bve)

Do not let untrained individuals operate this equipment. Contact your Dealer, AEM ([www.aem.org](http://www.aem.org)), FEMA (314-878-2304, [www.FarmEquip.org](http://www.FarmEquip.org)), or Alamo Group ([www.Alamo-Group.com](http://www.Alamo-Group.com)) for information on training material or courses that provide training in Safer Operating Practices for Mowers.

D559



# INTRODUCTION

## BUSH HOG LIMITED WARRANTY



Bush Hog warrants to the original purchaser of any new Bush Hog equipment, purchased from an authorized Bush Hog dealer, that the equipment be free from defects in material and workmanship for a period of one (1) year for non-commercial, state and municipalities' use and ninety (90) days for commercial use from date of retail sale. The obligation of Bush Hog to the purchaser under this warranty is limited to the repair or replacement of defective parts.

Replacement or repair parts installed in the equipment covered by this limited warranty are warranted for ninety (90) days from the date of purchase of such part or to the expiration of the applicable new equipment warranty period, whichever occurs later. Warranted parts shall be provided at no cost to the user at an authorized Bush Hog dealer during regular working hours. Bush Hog reserves the right to inspect any equipment or parts which are claimed to have been defective in material or workmanship.

### DISCLAIMER OF IMPLIED WARRANTIES & CONSEQUENTIAL DAMAGES

Bush Hog's obligation under this limited warranty, to the extent allowed by law, is in lieu of all warranties, implied or expressed, **INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE** and any liability for incidental and consequential damages with respect to the sale or use of the items warranted. Such incidental and consequential damages shall include but not be limited to: transportation charges other than normal freight charges; cost of installation other than cost approved by Bush Hog; duty; taxes; charges for normal service or adjustment; loss of crops or any other loss of income; rental of substitute equipment, expenses due to loss, damage, detention or delay in the delivery of equipment or parts resulting from acts beyond the control of Bush Hog.

### THIS LIMITED WARRANTY SHALL NOT APPLY:

1. To vendor items which carry their own warranties, such as engines, tires, and tubes.
2. If the unit has been subjected to misapplication, abuse, misuse, negligence, fire or other accident.
3. If parts not made or supplied by Bush Hog have been used in connection with the unit, if, in the sole judgment of Bush Hog such use affects its performance, stability or reliability.
4. If the unit has been altered or repaired outside of an authorized Bush Hog dealership in a manner which, in the sole judgment of Bush Hog, affects its performance, stability or reliability.
5. To normal maintenance service and normal replacement items such as gearbox lubricant, hydraulic fluid, worn blades, or to normal deterioration of such things as belts and exterior finish due to use or exposure.
6. To expendable or wear items such as teeth, chains, sprockets, belts, springs and any other items that in the company's sole judgment is a wear item.

NO EMPLOYEE OR REPRESENTATIVE OF BUSH HOG IS AUTHORIZED TO CHANGE THIS LIMITED WARRANTY IN ANY WAY OR GRANT ANY OTHER WARRANTY UNLESS SUCH CHANGE IS MADE IN WRITING AND SIGNED BY BUSH HOG'S SERVICE MANAGER, 2501 GRIFFIN AVE., SELMA, ALABAMA 36703.



Record the model number, serial number and date purchased. This information will be helpful to your dealer if parts or service are required.

MODEL NUMBER \_\_\_\_\_

SERIAL NUMBER \_\_\_\_\_

MAKE CERTAIN THE WARRANTY  
HAS BEEN FILED WITH BUSH HOG  
SELMA, ALABAMA

DATE OF RETAIL SALE \_\_\_\_\_









# ASSEMBLY SECTION

Assembly Section 3-1



# ASSEMBLY

## **DEALER SET-UP INSTRUCTIONS**

This Road Grader is shipped completely assembled from the factory.

Upon receipt of the unit make a thorough inspection of the machine to insure it is complete and in good working order. Contact Bush Hog Service Department to report any shipping damage, defective or missing parts.



Always use personal protection devices such as eye and ear protectors during assembly.

ASSEMBLY



# OPERATION SECTION

Operation Section 4-1



# OPERATION

## ROAD GRADER OPERATING INSTRUCTIONS

Your Road Grader should now be assembled and inspected for any evidence of defective or damaged parts before use. Any evidence of damage should be reported to your dealer immediately. After the Three-Point Hitch is attached, carefully remove safety blocks from under the implement (if used).

This section of the Operator's Manual is designed to familiarize, instruct, and educate safe and proper blade use to the operator. Pictures contained in this section are intended to be used as a visual aid to assist in explaining the operation of a Grader blade and are not necessarily representative of this blade. Some pictures may show shields removed for purposes of clarity. NEVER OPERATE this implement without all shields in place and in good operational condition. The operator must be familiar with the blade and tractor operation and all associated safety practices before operating the blade and tractor. Proper operation of the blade, as detailed in this manual, will help ensure years of safe and satisfactory use of the Road Grader

**READ AND UNDERSTAND THE ENTIRE OPERATING INSTRUCTIONS AND SAFETY SECTION OF THIS MANUAL AND THE TRACTOR MANUAL BEFORE ATTEMPTING TO USE THE TRACTOR AND IMPLEMENT.** If you do not understand any of the instructions, contact your nearest authorized dealer for a full explanation. Pay close attention to all safety signs and safety messages contained in this manual and those affixed to the implement and tractor. *OPS-U- 0001str*

READ, UNDERSTAND, and FOLLOW the following Safety Messages. Death or serious injury may occur unless care is taken to follow the warnings and instructions stated in the Safety Messages. Always use good common sense to avoid hazards. (SG-2str)





# OPERATION

## 1. STANDARD EQUIPMENT AND SPECIFICATIONS

|                                | RG60                                     | RG72           | RG84           | CRG48                     | CRG60          |
|--------------------------------|--|----------------|----------------|---------------------------|----------------|
| Working Width                  | 60-3/16"                                 | 72-3/16"       | 84-3/16"       | 52-3/16"                  | 64-3/16"       |
| Box Depth                      | 49-3/8"                                  | 49-3/8"        | 49-3/8"        | 44"                       | 44"            |
| Overall Height                 | 49"                                      | 49"            | 49"            | 28-1/2"                   | 28-1/2"        |
| Overall Width                  | 65"                                      | 77"            | 89"            | 48"                       | 60"            |
| Side Sheet Thickness           | 3/16"                                    | 3/16"          | 3/16"          | 3/16"                     | 3/16"          |
| Shank Penetration              | 5/8" - 2-1/2"                            | 5/8" - 2-1/2"  | 5/8" - 2-1/2"  | N/A                       | N/A            |
| Shank Size                     | 3/4"x 2-1/2"                             | 3/4"x 2-1/2"   | 3/4"x 2-1/2"   | N/A                       | N/A            |
| Mainframe                      | 4"x 4"x5 / 16"                           | 4"x 4"x5 / 16" | 4"x 4"x 5/ 16" | 3"x 3"x 3/ 16"            | 3"x 3"x 3/ 16" |
| HP Rating Max                  | 50hp- 2 Wheel Drive & 40hp- 4Wheel Drive |                |                | 25hp - 2 WD & 18hp - 4 WD |                |
| Hitch Type                     | CAT I & QH                               | CAT I & QH     | CAT I & QH     | CAT I & QH                | CAT I & QH     |
| Lower Hitch                    | Double Lug                               | Double Lug     | Double Lug     | Single Lug                | Single Lug     |
| Cutting Edge                   | 1/2"x 6"                                 | 1/2"x 6"       | 1/2"x 6"       | 3/8"x 6"                  | 3/8"x 6"       |
| Number of Blades               | 2  | 2              | 2              | 2                         | 2              |
| Weight, approx. (w/Scarifiers) | 500 lbs                                  | 571 lbs        | 642 lbs        | N/A                       | N/A            |
| Weight, approx. (no shanks)    |  |                |                | 400 lbs                   | 471 lbs        |



# OPERATION

## OPERATION

### 2. OPERATOR REQUIREMENTS

Safe operation of the unit is the responsibility of a qualified operator. A qualified operator has read and understands the implement and tractor Operator's Manuals and is experienced in implement and tractor operation and all associated safety practices. In addition to the safety messages contained in this manual, safety signs are affixed to the implement and tractor. If any part of the operation and safe use of this equipment is not completely understood, consult an authorized dealer for a complete explanation.


If the operator cannot read the manuals for themselves or does not completely understand the operation of the equipment, it is the responsibility of the supervisor to read and explain the manuals, safety practices, and operating instructions to the operator.

Safe operation of equipment requires that the operator wear approved Personal Protective Equipment (PPE) for the job conditions when attaching, operating, servicing, and repairing the equipment. PPE is designed to provide operator protection and includes the following safety wear:

#### PERSONAL PROTECTIVE EQUIPMENT (PPE)


- Always Wear Safety Glasses (with side shields marked to comply with ANSI Z87)
- Hard Hat
- Steel Toe Safety Footwear
- Gloves
- Hearing Protection
- Close Fitting Clothing
- Respirator or Filter Mask (depends on operating conditions)

OPS-U- 0002str



#### **⚠ DANGER**

DO NOT use drugs or alcohol immediately before or while operating the Tractor and Implement. Drugs and alcohol will affect an operator's alertness and coordination and therefore affect the operator's ability to operate the equipment safely. Before operating the Tractor or Implement, an operator on prescription or over-the-counter medication must consult a medical professional regarding any side effects of the medication that would hinder their ability to operate the Equipment safely. NEVER knowingly allow anyone to operate this equipment when their alertness or coordination is impaired. Serious injury or death to the operator or others could result if the operator is under the influence of drugs or alcohol. (SG-27) str





# OPERATION

## 3. TRACTOR REQUIREMENTS

Operating the grader with a tractor that does not meet the following requirements may cause tractor or implement damage and be a potential danger to the operator and passersby.

### Tractor Requirements and Capabilities

- Certified approved Roll-Over Protective Structure (ROPS) or ROPS cab and seat belt.
- Tractor Safety Devices ..... Slow Moving Vehicle (SMV) emblem, lighting, PTO master shield
- Tractor Horsepower RG Models ..... Max 40 PTO HP-4 Wheel Drive & 50 PTO HP - 2 Wheel Drive
- Tractor Horsepower CRG Models .....Max 18 PTO HP-4 Wheel Drive & 25 PTO HP - 2 Wheel Drive
- Hitch - 3 Point Hitch RG Models .....CAT I & QH
- Hitch - 3 Point Hitch CRG Models .....CAT 0 & 1; CAT 1 QH
- Front End WeightsAs needed to maintain 20% weight on front axle

### 3.1 ROPS and Seat Belt

The tractor must be equipped with a Roll-Over-Protective-Structure (ROPS) (tractor cab or roll-bar) and seat belt to protect the operator from falling off the tractor, especially during a roll over where the driver could be crushed and killed. Only operate the tractor with the ROPS in the raised position and seat belt fastened. Tractor models not equipped with a ROPS and seat belt should have these life saving features installed by an authorized dealer. OPS-U- 0003str



Operate this Equipment only with a Tractor equipped with an approved roll-over-protective system (ROPS). Always wear seat belts. Death or serious injury could result from falling off the tractor, particularly during a turnover when the operator could be pinned under the ROPS. (SG-7) str



### 3.2 Tractor Horsepower

The power required to operate these implements is determined by the tractor PTO horsepower. For most operating conditions, the Road Graders require a tractor with the maximum of 40 PTO HP- 4 wheel drive and 50 PTO HP for 2 wheel drive. Operating these implements with a tractor that does not have adequate power may damage the tractor engine. Exceeding the recommended horsepower may cause road grader damage by overpowering the unit in heavy operating conditions.




# OPERATION

## 3.3 Tractor 3-Point Hitch - RG Models

For the RG Models the tractor 3-point hitch must be rated to lift at least 500 lbs. for the 60", 571lbs for the 72", and 642 lbs. for the 84".

The Road Grader can attach to tractors with a CAT 0 or I hitch. Refer to the tractor operator's manual for the category of the tractor used. If the hitch does not conform to the ASAE CAT I dimensions, the implements may not fit or raise properly. Consult an authorized dealer for possible modification procedures to mount nonconforming hitches.

Use the correct hitch pins for the hitch category being used. For a Cat I hitch, 7/8" lower hitch pins are used, and 3/4" top hitch pins are used.



### CAT I Implement / Hitch Specification

|                                       |         |
|---------------------------------------|---------|
| Width from outside to outside A-frame | 26-7/8" |
| Quick Hitch width inside lug to lug   | 27-1/8" |
| Height from bottom hitch to top pin   | 18"     |
| Lower pin diameter                    | 7/8"    |
| Upper pin diameter                    | 3/4"    |
| Lynch pin diameter                    | 15/32"  |




# OPERATION

## 3.4 Tractor 3-Point Hitch - CRG Models

For the CRG Model the tractor 3-point hitch must be rated to lift at least 400 lbs. for the 48', and 471 lbs. for the 60". .

The Road Grader can attach to tractors with a CAT 0 or I hitch. Refer to the tractor operator's manual for the category of the tractor used. If the hitch does not conform to the ASAE CAT I dimensions, the implements may not fit or raise properly. Consult an authorized dealer for possible modification procedures to mount nonconforming hitches.

Use the correct hitch pins for the hitch category being used. For a Cat I hitch, 7/8" lower hitch pins are used, and 3/4" top hitch pin is used.



| CAT I Implement / Hitch Specification<br>(from Factory) |        | CAT 0 Implement / Hitch Specification<br>(from Factory) |        |
|---|--------|---|--------|
| Width from outside to outside A-frame                   | 25"    | Width from outside to outside A-frame                   | 25"    |
| Quick Hitch width inside lug to lug                     | 24     | Quick Hitch width inside lug to lug                     | 24"    |
| Height from bottom hitch to top pin                     | 18"    | Height from bottom hitch to top pin                     | 15"    |
| Lower pin diameter                                      | 7/8"   | Lower pin diameter                                      | 5/8"   |
| Upper pin diameter                                      | 3/4"   | Upper pin diameter                                      | 5/8"   |
| Lynch pin diameter                                      | 15/32" | Lynch pin diameter                                      | 15/32" |

## 3.5 Front End Weight

A minimum of 20% total tractor weight must be maintained on the tractor front end at all times. Front end weight is critical to maintain steering control and to prevent the tractor from rearing up while driving. If the front end is too light, add weight until a minimum of 20% total weight is reached on the front tires. Front weights and weight carriers can be purchased through an authorized tractor dealership. OPS-U-0005 str

## 4.GETTING ON AND OFF THE TRACTOR

Before getting onto the tractor, the operator must read and completely understand the implement and tractor operator manuals. If any part of either manual is not completely understood, consult an authorized dealer for a complete explanation. OPS-U- 0007str



Do not mount or dismount the Tractor while the tractor is moving. Mount the Tractor only when the Tractor and all moving parts are completely stopped. Dismounting a moving power unit can result in a crushing hazard that can cause death or serious injury. (SG-12) str





# OPERATION

## OPERATION

### 4.1 Boarding the Tractor

Use both hands and equipped handrails and steps for support when boarding the tractor. Never use control levers for support when mounting the tractor. Seat yourself in the operator's seat and secure the seat belt around you.

Never allow passengers to ride on the tractor or attached equipment. Riders can easily fall off and be seriously injured or killed from falling off and being ran over. It is the operator's responsibility to forbid all extra riders at all times. OPS-U- 0008str



Never allow children to operate, ride on, or come close to the Tractor or Implement. Usually, 16-17 year-old children who are mature and responsible can operate the implement with adult supervision, if they have read and understand the Operator's Manuals, been trained in proper operation of the tractor and Implement, and are physically large enough to reach and operate the controls easily. (SG-11) str



Never allow children or other persons to ride on the Tractor or Implement. Falling off can result in death or serious injury. (SG-10)str




### 4.2 Dismounting the Tractor

Before dismounting, park the tractor and implement on a reasonably level surface, apply the parking brake, idle the engine down, disengage the PTO, and lower the implement to the ground. Shut down the tractor engine according to the operator's manual, remove the key, and wait for all motion to completely stop. Never leave the seat until the tractor, its engine and all moving parts have come to a complete stop.

Use hand rails and steps when exiting the tractor. Be careful of your step and use extra caution when mud, ice, snow or other matter has accumulated on the steps or hand rails. Use all handrails and steps for support and never rush or jump off the tractor. OPS-U- 0009 str



BEFORE leaving the tractor seat lower the implement, set the parking brake and/or set the tractor transmission in parking gear, disengage the PTO, stop the engine, remove the key, and wait for all moving parts to stop. Place the tractor shift lever into a low range or parking gear to prevent the tractor from rolling. Never dismount a Tractor that is moving or while the engine is running. Operate the Tractor controls from the tractor seat only. (SG-9)str





# OPERATION

## **5. STARTING THE TRACTOR**

The operator must have a complete understanding of the placement, function, and operational use of all tractor controls before starting the tractor. Review the tractor operator's manual and consult an authorized dealer for tractor operation instructions if needed.

### **Essential Tractor Controls:**

- Locate the light control switch.
- Locate the engine shut off control.
- Locate the brake pedals and the clutch.
- Locate the PTO control.
- Locate the 3-point hitch control lever.
- Locate the hydraulic remote control levers

### **Before starting the tractor ensure the following:**

- Conduct all pre-start operation inspection and service according to the tractor operator's manual.
- Make sure all guards, shields, and other safety devices are securely in place.
- The parking brake is on.
- The PTO control lever is disengaged.
- The 3-point hitch control lever is in the lowered position.
- The hydraulic remote control levers are in the neutral position.
- The tractor transmission levers are in park or neutral.

Refer to the tractor owner's manual for tractor starting procedures. Only start the tractor while seated and belted in the tractor operator's seat. Never bypass the ignition switch by short circuiting the starter solenoid. After the tractor engine is running, avoid accidental contact with the tractor transmission to prevent sudden and unexpected tractor movement. OPS-U-0028str



Never run the Tractor engine in a closed building or without adequate ventilation. The exhaust fumes can be hazardous to your health. (SG-23) str



Start tractor only when properly seated in the Tractor seat. Starting a tractor in gear can result in death or serious injury. Read the Tractor operators manual for proper starting instructions. (SG-13) str



## **6.CONNECTING THE IMPLEMENT TO THE TRACTOR**

Use extreme caution when connecting the implements to the tractor. The implement should be securely resting at ground level or setting on blocks. Keep hands and feet from under the units and clear of pinch points between the tractor hitch arms and implement pins. OPS-0011\_B str



Always shut the Tractor completely down, place the transmission in park, and set the parking brake before you or anyone else attempts to connect or disconnect the Implement and Tractor hitches. (S3PT-15) str



# OPERATION

## OPERATION



### 6.1 Connecting the Road Grader

1. Shorten or remove the tractor drawbar to avoid interference when raising and lowering the road grader

2. Board the tractor and start the engine. Position the tractor to the road grader with the 3-point lift arms positioned between the respective set of road grader A-frame lift lugs.

**Note:** Set the 3-point lift control to "Position Control" so that the lift arms maintain a constant height when attaching the road grader or rake. See the tractor Operator's Manual for correct settings when attaching 3-point equipment.

3. Turn off the tractor engine, set the parking brake, place the tractor in park, and dismount.
4. One lift arm at a time, align arm end hole between the set of holes of A-frame lift lugs. Insert hitch pin through the lug and arm holes and insert retaining pin into hitch pin. Walk around to opposite side and repeat procedure for remaining lift arm and hitch pin.
5. Extend or retract the 3-point top link to align its end hole with the holes of the road grader top link. Insert the top link pin and retain with cotterpin on RG Models and nut on CRG Models.
6. Adjust any lower link check chains, guide blocks, or sway blocks to prevent the road grader or rake from swaying side to side and possible contact with tractor rear tires.



**IMPORTANT:** Scan this QR Code with your smart phone to link to the PAMI Safe Implement Hitching Manual for more information on correctly connecting agricultural tractors to implements. Or type in your internet browser the following web address: [www.algqr.com/hme](http://www.algqr.com/hme) Ops-0008-MISC str






# OPERATION

## **7. PRE-OPERATION INSPECTION AND SERVICE**

Before each use, a pre-operation inspection and service of the implement and tractor must be performed. This includes routine maintenance and scheduled lubrication, inspecting that all safety devices are equipped and functional, and performing needed repairs. DO NOT operate the unit if the pre-operation inspection reveals any condition affecting safe operation. Perform repairs and replacement of damaged and missing parts as soon as noticed. By performing a thorough pre-operation inspection and service, valuable down time and repair cost can be avoided. OPS-U-0029str



Periodically inspect all moving parts for wear and replace when necessary with authorized service parts. Look for loose fasteners, worn or broken parts, and leaky or loose fittings. Make sure all pins have cotter pins and washers. Serious injury may occur from not maintaining this machine in good working order. (SG-21 )str



### **7.1 Tractor Pre-Operation Inspection/Service**

Refer to the tractor operator's manual to ensure a complete pre-operation inspection and scheduled service is performed according to the manufacturers recommendations. The following are some of the items that require daily service and inspection:

- Tire condition/air pressure
- Wheel lug bolts
- Steering linkage
- PTO shield
- SMV sign is clean and visible
- Tractor's lights are clean and functional
- Tractor Seat belt is in good condition
- ROPS is in the raised position
- No tractor oil leaks
- Radiator free of debris
- Engine oil level and condition
- Engine coolant level and condition
- Power brake fluid level
- Power steering fluid level
- Fuel condition and level
- Sufficient lubrication at all lube points
- Air filter condition OPS-U-0030 str





# OPERATION

## 7.2 Blade Pre-Operation Inspection/Service

Before each use, a complete inspection and service is required to ensure the blade is in good and safe working condition. Damaged and/or broken parts should be repaired and/or replaced immediately. To ensure the blade is ready for operation, conduct the following. *OPS- 0020\_ C str*



Periodically inspect all moving parts for wear and replace when necessary with authorized service parts. Look for loose fasteners, worn or broken parts, and leaky or loose fittings. Make sure all pins have cotter pins and washers. Serious injury may occur from not maintaining this machine in good working order. (SG-21 )str



OPERATION

The operator's manual and safety signs affixed on the unit contain important instructions on the safe and proper use of the equipment. Maintain these important safety features on the implement in good condition to ensure the information is available to the operator at all times.

- Ensure the manual canister is secured to the equipment with the operator's manual inside.
- Ensure all safety signs are in place and legible. Replace missing, damaged, and illegible decals. *OPS-U- 0011 str*





# OPERATION

## BLADE & BOX BLADE PRE-OPERATION INSPECTION



Blade ID# \_\_\_\_\_

Date : \_\_\_\_\_

Make: \_\_\_\_\_

Shift: \_\_\_\_\_



### WARNING

Before conducting the inspection, make sure the tractor engine is off, all rotation has stopped and the tractor is in park with the parking brake engaged. Make sure the blade is resting on the ground or securely blocked up and all hydraulic pressure has been relieved.

| Item   | Condition at Start of Shift | Specific Comments if not OK |
|--|-----------------------------|-----------------------------|
| The Operator's Manual is in the canister                                 |                             |                             |
| All safety decals are in place and legible                               |                             |                             |
| The hitch connection pins are properly retained                          |                             |                             |
| There are no cracks in the Hitch   |                             |                             |
| All frame bolts are in place and tight                                   |                             |                             |
| The blade swing, angle & tilt pins are properly lubricated and retained. |                             |                             |
| The Blade edge & moldboard are clear of mud and debris.                  |                             |                             |
| The blade edge attachment bolts are in place and tight.                  |                             |                             |
| The blade edge is not chipped, cracked or bent.                          |                             |                             |
| The Storage Stands are in place & in good condition.                     |                             |                             |
| The skid shoes are in good condition.                                    |                             |                             |
| The hydraulic cylinder pins are in place and retained.                   |                             |                             |
| There are no leaking or damaged hoses.                                   |                             |                             |
| There is no evidence of hydraulic leaks.                                 |                             |                             |
| The gauge wheel(s) are in good condition & lubricated.                   |                             |                             |
| The scarifier shanks are properly retained.                              |                             |                             |
| The scarifier points are in good condition.                              |                             |                             |

Operator's Signature: \_\_\_\_\_

**DO NOT OPERATE an UNSAFE TRACTOR or IMPLEMENT**

OPERATION



# OPERATION

## TRACTOR PRE-OPERATION INSPECTION



Tractor ID# \_\_\_\_\_ Make: \_\_\_\_\_

Date: \_\_\_\_\_ Shaft: \_\_\_\_\_



### WARNING

Before conducting the inspection, make sure the tractor engine is off, all rotation has stopped and the tractor is in park with the parking brake engaged. Make sure the mower is resting on the ground or securely blocked up and all hydraulic pressure has been relieved.

| Item   | Condition at Start of Shift | Specific Comments if not OK |
|--|-----------------------------|-----------------------------|
| The flashing lights function properly                |                             |                             |
| The SMV Sign is clean and visible                    |                             |                             |
| The tires are in good condition with proper pressure |                             |                             |
| The wheel lug bolts are tight                        |                             |                             |
| The tractor brakes are in good condition             |                             |                             |
| The steering linkage is in good condition            |                             |                             |
| There are no visible oil leaks                       |                             |                             |
| The hydraulic controls function properly             |                             |                             |
| The ROPS or ROPS Cab is in good condition            |                             |                             |
| The seatbelt is in place and in good condition       |                             |                             |
| The 3-point hitch is in good condition               |                             |                             |
| The drawbar pins are securely in place               |                             |                             |
| The PTO master shield is in place                    |                             |                             |
| The engine oil level is full                         |                             |                             |
| The brake fluid level is full                        |                             |                             |
| The power steering fluid level is full               |                             |                             |
| The fuel level is adequate                           |                             |                             |
| The engine coolant fluid level is full               |                             |                             |
| The radiator is free of debris                       |                             |                             |
| The air filter is in good condition                  |                             |                             |

Operator's Signature: \_\_\_\_\_

**DO NOT OPERATE an UNSAFE TRACTOR or MOWER**



# OPERATION

## 8.DRIVING THE TRACTOR AND IMPLEMENT

Safe tractor transport requires the operator possess a thorough knowledge of the model being operated and precautions to take while driving with an attached implement. Ensure the tractor has the capacity to handle the weight of the implement and the tractor operating controls are set for safe transport. To ensure safety while driving the tractor with an attached implement, review the following. OPS-U- 0012str



This Implement may be wider than the Tractor. Be careful when operating or transporting this equipment to prevent the Implement from running into or striking sign posts, guard rails, concrete abutments or other solid objects. Such an impact could cause the Implement and Tractor to pivot violently resulting in loss of steering control, death, or serious injury. Never allow the Implement to contact obstacles. (S3PT-12)str



Transport only at speeds where you can maintain control of the equipment. Serious accidents and injuries can result from operating this equipment at high speeds. Understand the Tractor and Implement and how it handles before transporting on streets and highways. Make sure the Tractor steering and brakes are in good condition and operate properly.



Before transporting the Tractor and Implement, determine the proper transport speeds for you and the equipment. Make sure you abide by the following rules:

Test the tractor at a slow speed and increase the speed slowly. Apply the Brakes smoothly to determine the stopping characteristics of the Tractor and Implement. As you increase the speed of the Tractor the stopping distance increases. Determine the maximum transport speed not to exceed 20 mph (30 kph) for transporting this equipment.

Test the equipment at a slow speed in turns. Increase the speed through the turn only after you determine that the equipment can be operated at a higher speed. Use extreme care and reduce your speed when turning sharply to prevent the tractor and implement from turning over. Determine the maximum turning speed for you and this equipment before operating on roads or uneven ground.

Only transport the Tractor and Implement at the speeds which allow you to properly control the equipment.

Be aware of the operating conditions. Do not operate the Tractor with weak or faulty brakes or worn tires. When operating down a hill or on wet or rain slick roads, the braking distance increases: use extreme care and reduce your speed. When operating in traffic always use the Tractor's flashing warning lights and reduce your speed. Be aware of traffic around you and watch out for the other guy. (SG-19)str





# OPERATION

## OPERATION

### **8.1 Starting the Tractor**


The procedure to start the tractor is model specific. Refer to the tractor operator's manual for starting procedures for your particular tractor. Consult an authorized dealer if the starting procedure is unclear. Ensure the 3-point control lever is in the lowered position and the PTO is disengaged before starting the tractor. OPS-U-0033str



### **8.2 Brake and Differential Lock Setting**

Make sure the tractor brakes are in good operating condition. Tractor brakes can be set to operate independently allowing single rear wheel braking action or locked together to provide simultaneous rear wheel braking. FOR MOST DRIVING AND OPERATING CONDITIONS, THE BRAKE PEDALS SHOULD BE LOCKED TOGETHER TO PROVIDE THE MOST EFFECTIVE BRAKING ACTION.

Always disengage the tractor differential lock when turning. When engaged the differential lock will prevent or limit the tractor from turning. During normal cutting conditions, locking the differential provides no benefit and should not be used.



#### **⚠ WARNING**

Be aware of the operating conditions. Do not operate the Tractor with weak or faulty brakes. When operating down a hill or on wet or rain slick roads, the braking distance increases. Use extreme care and reduce your speed in these conditions. When operating in traffic, always use the Tractor's flashing warning lights and reduce your speed. Be aware of traffic around you and watch out for the other guy. OPS-U- 0013 str

### **8.3 Driving the Tractor and Implement**

Start off driving at a slow speed and gradually increase your speed while maintaining complete control of the tractor and unit. Moving slowly at first will also prevent the tractor from rearing up and loss of steering control. The tractor should never be operated at speeds that cannot be safely handled or which will prevent the operator from stopping quickly during an emergency. If the power steering or engine ceases operating, stop the tractor immediately as the tractor will be difficult to control.

Perform turns with the tractor and units at slow speeds to determine how the tractor with an attached blade handles a turn. Determine the safe speed to maintain proper control of the tractor when making turns. When turning with a towed implement, the overall working length of the unit is increased. Allow additional clearance for the units when turning.



# OPERATION

To avoid overturns, drive the tractor with care and at safe speeds, especially when operating over rough ground, crossing ditches or slopes, and turning corners. Tractor wheel tread spacing should be increased when working on inclines or rough ground to reduce the possibility of tipping.

Use extreme caution when operating on steep slopes. Keep the tractor in a low gear when going downhill. DO NOT coast or free-wheel downhill

## **8.4 Operating the Tractor and Implement**

**THE OPERATOR MUST COMPLETELY UNDERSTAND HOW TO OPERATE THE TRACTOR AND IMPLEMENT AND ALL CONTROLS BEFORE ATTEMPTING TO OPERATE.**

The operator must read and understand the Safety and Operation Sections of the implement and tractor operator's manuals. These manuals must be read and explained to any operator who cannot read. Never allow someone to operate the implement and tractor without complete operating instructions.

Before starting any operation, the operator must become familiar with the area to be worked in and any obstacles and hazards contained within to ensure safety to the operator, bystanders, and equipment. Special attention should be paid to foreign debris, rough terrain, steep slopes, and passersby and animals in the area.  
*OPS-U- 0015 str*

## **8.5 Operating the Grader**

When operating the Road Grader, a reasonable degree of care should be taken to avoid large obstacles that would create undue loads on both the grader and linkage which could result in damage to your unit. Use "Float Position" while operating unit. Do not use down pressure. Always operate at a slow speed.

## **8.6 Backfilling and Snow Removal**

The backfilling operation should be performed with the load in the center of the road grader. Avoid concentrated loads on end of the road grader. DO NOT ram into a load at any time, as this multiplies the force several times above normal and could result in damage to your road grader. Perform all backfilling operations at slow speeds to prevent damage if road grader hits an object.


Moving snow with the road grader in backfill position is a very delicate operation and should be performed with extreme care and very slow speed. It is very easy to hit objects hidden in snow, or hit a snow bank that is too much material for your road grader to move. This could damage your road grader or mainframe. Caution in snow removal should be taken, as tractor could lose and regain traction causing surge in ground speed.

In all backfilling operations, the top link setting is very critical. Lengthen the top link so the road grader is tilted down at the rear in order that the road grader moves across the ground, not digging into it.

## **9.SHUTTING DOWN THE IMPLEMENT**

To shut down the implement, first bring the tractor to a complete stop.

Park the tractor on a level surface, place the transmission in park or neutral and apply the parking brake, lower the attached implement to the ground, shut down the engine, remove the key, before exiting the tractor.





# OPERATION

## OPERATION

### **10.DISCONNECTING THE BLADE FROM THE TRACTOR**

Before disconnecting the blade, all movement must cease. Move the blade to a level storage location and lower the unit to the ground. If the blade is not resting securely on the ground, block the blade up securely before attempting to disconnect it from the tractor.

Use extreme care to keep feet and hands from under the blade and clear of any pinch points. OPS- 0051\_Astr



**DANGER**

Always shut the Tractor completely down, place the transmission in park, and set the parking brake before you or anyone else attempts to connect or disconnect the Implement and Tractor hitches. (S3PT-15) str

When disconnecting the road grader the tractor should be completely shut down and secured in position, by lowering the road grader. Relieve hydraulic pressure by moving the control levers back and forth several times. Then extend the tractor 3-point hitch top link to remove tension on the top link hitch pin. When the pin is loose and easy to rotate, remove the pin from the road grader. Next remove both lower hitch pins.

### **11.ROAD GRADER AND STORAGE**

Properly preparing and storing the implement at the end of the season is critical to maintaining its appearance and to help ensure years of dependable service. The following are suggested storage procedures:

- Thoroughly clean all debris off the unit to prevent damage from rotting grass and standing water.
- Lubricate all grease points as detailed in the maintenance section.
- Tighten all bolts and pins to the recommended torque.
- Check the unit for worn and damaged parts. Perform repairs and make replacements immediately so that the unit will be ready for use at the start of the next season.
- Store the unit in a clean, dry place with the implement resting securely on blocks or at ground level.
- Use spray touch-up enamel where necessary to prevent rust and maintain the appearance of the unit.



**DANGER**

Never allow children to play on or around Tractor or Implement. Children can slip or fall off the Equipment and be killed or injured. Inadvertent contact with controls can cause the Implement to shift or fall crushing themselves or others. (SG-25) str

### **12.TRANSPORTING THE TRACTOR AND IMPLEMENT**

Inherent hazards of operating the tractor and implement and the possibility of accidents are not left behind when you finish working in an area. Therefore, the operator must employ good judgment and safe operation practices when transporting the tractor and implement between locations. By using good judgment and following safe transport procedures, the possibility of accidents while moving between locations can be substantially minimized. OPS-U- 0017str

### **13.DRIVING THE TRACTOR AND IMPLEMENT**

Safe tractor transport requires the operator possess a thorough knowledge of the model being operated and precautions to take while driving with an attached implement. Ensure the tractor has the capacity to handle the weight of the implement and the tractor operating controls are set for safe transport. To ensure safety while driving the tractor with an attached implement, review the following. OPS-U- 0012str



# OPERATION



This Implement may be wider than the Tractor. Be careful when operating or transporting this equipment to prevent the Implement from running into or striking sign posts, guard rails, concrete abutments or other solid objects. Such an impact could cause the Implement and Tractor to pivot violently resulting in loss of steering control, death, or serious injury. Never allow the Implement to contact obstacles. (S3PT-12)str



Transport only at speeds where you can maintain control of the equipment. Serious accidents and injuries can result from operating this equipment at high speeds. Understand the Tractor and Implement and how it handles before transporting on streets and highways. Make sure the Tractor steering and brakes are in good condition and operate properly.



Before transporting the Tractor and Implement, determine the proper transport speeds for you and the equipment. Make sure you abide by the following rules:

Test the tractor at a slow speed and increase the speed slowly. Apply the Brakes smoothly to determine the stopping characteristics of the Tractor and Implement. As you increase the speed of the Tractor the stopping distance increases. Determine the maximum transport speed not to exceed 20 mph (30 kph) for transporting this equipment.

Test the equipment at a slow speed in turns. Increase the speed through the turn only after you determine that the equipment can be operated at a higher speed. Use extreme care and reduce your speed when turning sharply to prevent the tractor and implement from turning over. Determine the maximum turning speed for you and this equipment before operating on roads or uneven ground.

Only transport the Tractor and Implement at the speeds which allow you to properly control the equipment.

Be aware of the operating conditions. Do not operate the Tractor with weak or faulty brakes or worn tires. When operating down a hill or on wet or rain slick roads, the braking distance increases: use extreme care and reduce your speed. When operating in traffic always use the Tractor's flashing warning lights and reduce your speed. Be aware of traffic around you and watch out for the other guy. (SG-19)str



Never allow children or other persons to ride on the Tractor or Implement. Falling off can result in death or serious injury. (SG-10)str





# OPERATION

## OPERATION

Before transporting the tractor on a public roadway or boarding a trailer for transport, the tractor brake pedals should be locked together. Locking the pedals ensures that both wheels brake simultaneously while stopping, especially when making an emergency stop.

Use extreme caution and avoid hard applications of the tractor brakes when towing heavy loads at road speeds. Never tow the implement at speeds greater than 20 MPH (32 kph). OPS-U- 0018str



### 13.1 Transporting on Public Roadways

Extreme caution should be used when transporting the tractor and implement on public roadways. The tractor must be equipped with all required safety warning features including a SMV emblem and flashing warning lights to alert drivers of the tractor's presence. Remember that roadways are primarily designed for automotive drivers and most drivers will not be looking out for you, therefore, you must look out for them. Check your side view mirrors frequently and remember that vehicles will approach quickly because of the tractor's slower speed. Be extremely cautious when the piece of equipment that you are towing is wider than the tractor tire width and/or extends beyond your lane of the road. OPS-BL-0003str




Only tow the Implement behind a properly sized and equipped Tractor which exceeds the weight of the Implement by at least 20%. DO NOT tow the Implement behind a truck or other type of vehicle. Never tow the Implement and another Implement connected in tandem. Never tow the Implement at speeds over 20 MPH. (STI-06)str



Never allow children or other persons to ride on the Tractor or Implement. Falling off can result in death or serious injury. (SG-10)str



Make certain that the "Slow Moving Vehicle" (SMV) sign is installed in such a way as to be clearly visible and legible. When transporting the Equipment use the Tractor flashing warning lights and follow all local traffic regulations. (SG-6)str





# OPERATION

The SMV (Slow-Moving Vehicle) emblem is a universal symbol used to alert drivers of the presence of equipment traveling on roadways at a slow speed. SMV signs are a triangular bright orange with reflective red trim for both easy day and night visibility. Make sure the SMV sign is clean and visible from the rear of the unit before transporting the tractor and implement on a public roadway. Replace the SMV emblem if faded, damaged, or no longer reflective. OPS-U- 0020str



Make sure that all tractor flashing warning lights, headlights, and brake/tail lights are functioning properly before proceeding onto public roads. While newer model tractors have plenty of lighting to provide warning signals and operating lighting, most older models are only equipped with operating lights. Consult an authorized tractor dealer for lighting kits and modifications available to upgrade the lighting on older tractor models. OPS-U- 0021str



When operating on public roads, have consideration for other road users. Pull to the side of the road occasionally to allow all following traffic to pass. Do not exceed the legal speed limit set in your country for agricultural tractors. Always stay alert when transporting the tractor and implement on public roads. Use caution and reduce speed if other vehicles or pedestrians are in the area.

Reduce speed before turning or applying the brakes. Ensure that both brake pedals are locked together when operating on public roads. OPS-U- 0023 str





## OPERATION

### OPERATION

### **13.2 Hauling the Tractor and Implement**

Before transporting a loaded tractor and implement, measure the height and width dimensions and gross weight of the complete loaded unit. Ensure that the load will be in compliance with the legal limits set for the areas that will be traveled through. OPS-U- 0024str



Use adequately sized and rated trailers and equipment to transport the tractor and implement. Consult an authorized dealer to determine the proper equipment required. Using adequately sized chains, heavy duty straps, cables and/or binders, securely tie down both the front and rear of the tractor utilizing the proper tie down locations as specified by the tractor manufacturer. OPS-U-0025 str





# OPERATION

## 14. TROUBLESHOOTING GUIDE

| Problem   | Possible Cause                                   | Remedy  |
|---|--|---|
| Grader Will Not Penetrate Soil<br><b>RG MODELS ONLY</b> | Excessive Speed                                  | Reduce speed.                                   |
|   | Cutting edge is dull.                            | Replace cutting edge.                           |
|   | Grader set to straight.                          | Increase top link length.                       |
|   | Soil is too hard.                                | Use scarifiers to loosen soil                   |
| A-Frame Bent  | Hitting hidden objects in the backfill position. | Use slow speed when in unknown soil conditions. |
| Grader Digging in Too Much<br><b>RG MODELS ONLY</b>     | Grader pitch is excessive.                       | Adjust Top Link.                                |
|   | Excessive lifters down pressure.                 | Adjust lifters.                                 |
|   | Scarifiers set too deep.                         | Adjust scarifiers.                              |
| Unable to Hold Level Ground.                            | Tractor Draft Control lifting blade.             | Set Tractor Draft Control.                      |







# **MAINTENANCE SECTION**

Maintenance Section 5-1



# MAINTENANCE


## MAINTENANCE

### REPLACING SCARIFIER POINTS - (RG Models Only)



Make certain that you wear gloves and safety glasses. Chips can fly off hammer or punch and cause eye damage, loss of eyesight, or other injury.

Place Scarifier assembly in vise securely. Using a hammer and drift or punch, drive the worn point off. Hammer the new point on securely. Using a hammer and punch, indent the point edge into the recess in side of scarifier.



### PROPER TORQUE FOR FASTENERS

The chart lists the correct tightening torque for fasteners. When bolts are to be tightened or replaced, refer to this chart to determine the grade of bolts and the proper torque except when specific torque values are assigned in manual text.

Recommended Torque in Foot Pounds Unless Otherwise Stated in the Manual\*


**NOTE:** *These values apply to fasteners as received from supplier, dry or when lubricated with normal engine oil. They do not apply if special graphited or molydisulphide greases or other extreme pressure lubricants are used. This applies to both UNF fine and UNC coarse threads.*



# MAINTENANCE

## TORQUE SPECIFICATIONS - DRY TORQUE


### AMERICAN Bolt Head Markings



Proper torque for American fasteners.  
Recommended Torque in Foot Pounds (Newton Meters).\*

| WRENCH<br>SIZE (IN.) "A" | BOLT DIAMETER<br>(IN.) "B" AND<br>THREAD SIZE | SAE<br>GRADE 2 | SAE<br>GRADE 5 | SAE<br>GRADE 8 |
|--------------------------|---|----------------|----------------|----------------|
| 7/16                     | 1/4 - 20 UNC                                  | 6 (7)          | 8 (11)         | 12 (16)        |
| 7/16                     | 1/4 - 28 UNF                                  | 6 (8)          | 10 (13)        | 14 (18)        |
| 1/2                      | 5/16 - 18 UNC                                 | 11 (15)        | 17 (23)        | 25 (33)        |
| 1/2                      | 5/16 - 24 UNF                                 | 13 (17)        | 19 (26)        | 27 (37)        |
| 9/16                     | 3/8 - 16 UNC                                  | 20 (27)        | 31 (42)        | 44 (60)        |
| 9/16                     | 3/8 - 24 UNF                                  | 23 (31)        | 35 (47)        | 49 (66)        |
| 5/8                      | 7/16 - 14 UNC                                 | 32 (43)        | 49 (66)        | 70 (95)        |
| 5/8                      | 7/16 - 20 UNF                                 | 36 (49)        | 55 (75)        | 78 (106)       |
| 3/4                      | 1/2 - 13 UNC                                  | 49 (66)        | 76 (103)       | 106 (144)      |
| 3/4                      | 1/2 - 20 UNF                                  | 55 (75)        | 85 (115)       | 120 (163)      |
| 7/8                      | 9/16 - 12 UNC                                 | 70 (95)        | 109 (148)      | 153 (207)      |
| 7/8                      | 9/16 - 18 UNF                                 | 79 (107)       | 122 (165)      | 172 (233)      |
| 15/16                    | 5/8 - 11 UNC                                  | 97 (131)       | 150 (203)      | 212 (287)      |
| 15/16                    | 5/8 - 18 UNF                                  | 110 (149)      | 170 (230)      | 240 (325)      |
| 1-1/8                    | 3/4 - 10 UNC                                  | 144 (195)      | 266 (360)      | 376 (509)      |
| 1-1/8                    | 3/4 - 16 UNF                                  | 192 (260)      | 297 (402)      | 420 (569)      |
| 1-5/16                   | 7/8 - 9 UNC                                   | 166 (225)      | 430 (583)      | 606 (821)      |
| 1-5/16                   | 7/8 - 14 UNF                                  | 184 (249)      | 474 (642)      | 668 (905)      |
| 1-1/2                    | 1 - 8 UNC                                     | 250 (339)      | 644 (873)      | 909 (1232)     |
| 1-1/2                    | 1 - 12 UNF                                    | 274 (371)      | 705 (955)      | 995 (1348)     |
| 1-1/2                    | 1 - 14 UNF                                    | 280 (379)      | 721 (977)      | 1019 (1381)    |
| 1-11/16                  | 1-1/8 - 7 UNC                                 | 354 (480)      | 795 (1077)     | 1288 (1745)    |
| 1-11/16                  | 1-1/8 - 12 UNF                                | 397 (538)      | 890 (1206)     | 1444 (1957)    |
| 1-7/8                    | 1-1/4 - 7 UNC                                 | 500 (678)      | 1120 (1518)    | 1817 (2462)    |
| 1-7/8                    | 1-1/4 - 12 UNF                                | 553 (749)      | 1241 (1682)    | 2013 (2728)    |
| 2-1/16                   | 1-3/8 - 6 UNC                                 | 655 (887)      | 1470 (1992)    | 2382 (3228)    |
| 2-1/16                   | 1-3/8 - 12 UNF                                | 746 (1011)     | 1672 (2266)    | 2712 (3675)    |
| 2-1/4                    | 1-1/2 - 6 UNC                                 | 870 (1179)     | 1950 (2642)    | 3161 (4283)    |
| 2-1/4                    | 1-1/2 - 12 UNF                                | 979 (1327)     | 2194 (2973)    | 3557 (4820)    |

### METRIC



Proper torque for Metric fasteners.  
Recommended torque in Foot Pounds (Newton Meters).\*

| WRENCH<br>SIZE<br>(mm) "A" | BOLT<br>DIA.<br>(mm) "B" | ASTM<br>4.6 | ASTM<br>8.8 | ASTM<br>9.8 | ASTM<br>10.9 |
|----------------------------|--------------------------|-------------|-------------|-------------|--------------|
| 8                          | 5                        | 1.8 (2.4)   |             | 5.1 (6.9)   | 6.5 (8.8)    |
| 10                         | 6                        | 3 (4)       |             | 8.7 (12)    | 11.1 (15)    |
| 13                         | 8                        | 7.3 (10)    |             | 21.1 (29)   | 27 (37)      |
| 16                         | 10                       | 14.5 (20)   |             | 42 (57)     | 53 (72)      |
| 18                         | 12                       | 25 (34)     | 74 (100)    | 73 (99)     | 93 (126)     |
| 21                         | 14                       | 40 (54)     | 118 (160)   | 116 (157)   | 148 (201)    |
| 24                         | 16                       | 62 (84)     | 167 (226)   | 181 (245)   | 230 (312)    |
| 30                         | 20                       | 122 (165)   | 325 (440)   |             | 449 (608)    |
| 33                         | 22                       |             | 443 (600)   |             | 611 (828)    |
| 36                         | 24                       | 211 (286)   | 563 (763)   |             | 778 (1054)   |
| 41                         | 27                       |             | 821 (1112)  |             | 1138 (1542)  |
| 46                         | 30                       | 418 (566)   | 1119 (1516) |             | 1547 (2096)  |

\*Use 75% of the specified torque value for plated fasteners. Use 85% of the specified torque values for lubricated fasteners.

Mnt-B-0005









## TO THE OWNER/OPERATOR/DEALER

To keep your implement running efficiently and safely, read your manual thoroughly and follow these directions and the Safety Messages in this Manual. The Table of Contents clearly identifies each section where you can easily find the information you need.

The OCCUPATIONAL SAFETY AND HEALTH ACT (1928.51 Subpart C) makes these minimum safety requirements of tractor operators:

### REQUIRED OF THE OWNER:

1. Provide a Roll-Over-Protective Structure that meets the requirements of this Standard; and
2. Provide Seat belts that meet the requirements of this paragraph of this Standard and SAE J4C; and
3. Ensure that each employee uses such Seat belt while the tractor is moving; and
4. Ensure that each employee tightens the Seat belt sufficiently to confine the employee to the protected area provided by the ROPS

### REQUIRED OF THE OPERATOR:

1. Securely fasten seat belt if the tractor has a ROPS.
2. Where possible, avoid operating the tractor near ditches, embankments, and holes.
3. Reduce speed when turning, crossing slopes, and on rough, slick, or muddy surfaces.
4. Stay off slopes too steep for safe operation.
5. Watch where you are going - especially at row ends, on roads, and around trees.
6. Do not permit others to ride.
7. Operate the tractor smoothly - no jerky turns, starts, or stops.
8. Hitch only to the drawbar and hitch points recommended by the tractor manufacturer.
9. When the tractor is stopped, set brakes securely and use park lock, if available.

**X** Keep children away from danger all day, every day...

**X** Equip tractors with rollover protection (ROPS) and keep all machinery guards in place...

**X** Please work, drive, play and live each day with care and concern for your safety and that of your family and fellow citizens.





**RG 60/72/84 & CRG 48/60  
Road Grader**

---

RG60/72/84 & CRG 48/60-SOM 07-22  
Printed U.S.A

P/N 50069588