

# BUSH HOG®


# CROWNING GRADER SKID STEER MODEL BHCG84

Revised 03/24

## PARTS MANUAL SECTION 64



An Operator's Manual was shipped with the equipment. The Operator's Manual is an integral part of the safe operation of this machine and must be maintained with the unit at all times. **READ, UNDERSTAND, and FOLLOW** the Safety and Operation Instructions contained in this manual before operating the equipment. If the Operator's Manual is not with the equipment, contact your dealer or Bush Hog to obtain a Free copy before operating the equipment.



FC-BL-0045

### BUSH HOG®

2501 Griffin Ave.  
Selma, AL 36703  
Parts Ordering 1-800-304-2836  
www.bushhog.com

### ATENCIÓN!

LEA EL INSTRUCTIVO

Si No Lee Ingles, Pida Ayuda a Alguien  
Que Si Lo Lea Para Que le Traduzca las  
Medidas de Seguridad.



**MEMBER OF THE  
ALAMO GROUP**  
ALWAYS ON THE CUTTING EDGE®

© 2024 Alamo Group Inc.

## PARTS ORDERING GUIDE

The following instructions are offered to help eliminate needless delay and error in processing purchase orders for the equipment in this section.

1. The Parts Section is prepared in logical sequence and grouping of parts that belong to the basic machine featured in this manual. Part Numbers and Descriptions are given to help locate the parts and quantities required.
2. The Purchase Order must include the name and address of the person or organization ordering the parts, who should be charged, and if possible, the serial number of the machine for which the parts are ordered.
3. The Purchase Order must clearly list the quantity of each part, the complete and correct part number (be sure to include all periods), and the basic name of the part.
4. The Manufacturer reserves the right to substitute parts where applicable.
5. Some parts are unlisted items which are special production items not normally stocked and are subject to special handling. Request a quotation for such parts before sending a Purchase Order.
6. The Manufacturer reserves the right to change prices without prior notice.



For maximum safety and to guarantee optimum product reliability, always use genuine **BUSH HOG** Parts. The use of inferior replacement parts may cause premature or catastrophic failure which could result in serious injury or death. Direct any questions regarding parts to:


**BUSH HOG**  
2501 Griffin Ave.  
Selma, AL. 36703  
[www.bushhog.com](http://www.bushhog.com)  
Contact Us  
800-304-2836



## To the Owner/Operator/Dealer





All implements with moving parts are potentially hazardous. There is no substitute for a cautious, safe-minded operator who recognizes the potential hazards and follows reasonable safety practices. The manufacturer has designed this implement to be used with all its safety equipment properly attached to minimize the chance of accidents.

**BEFORE YOU START!** Read the safety messages on the implement and shown in your manual. Observe the rules of safety and common sense!



# DANGER

FAILING TO FOLLOW SAFETY MESSAGES AND OPERATING INSTRUCTION CAN CAUSE SERIOUS BODILY INJURY OR EVEN DEATH TO OPERATOR AND OTHERS IN THE AREA.

<p>1.</p> 	<p>2. NO RIDERS. NO CHILDREN OPERATORS.</p> 	<p>3. USE SAFETY SHOES, HARD HAT, SAFETY GLASSES, SEAT BELTS, ROPS &amp; OPS.</p> 	<p>4. BLOCK UP SECURELY BEFORE WORKING UNDER.</p> 
---	---	--	---

1. Study and understand Operator's Manuals, Safety Decals, and Instructional Decals for tractor and implement to prevent misuse, abuse, and accidents. Practice before operating in a confined area or near passersby.

- Learn how to stop engine suddenly in an emergency. Be alert for passersby and especially children.

2. Allow no children on or near folding mower or tractor. Allow no riders on tractor or implement. Falling off may cause serious injury or death from being run over by tractor or mower or contact with rotating blades.

3. Operate only with tractor having Roll-Over Protective Structure (ROPS) and with seat belt securely fastened to prevent injury and possible death from falling off or tractor overturn.

- Personal Protective Equipment such as Hard Hat, Safety Glasses, Safety Shoes, & Ear Plugs are recommended.

4. Block up or support raised machine and all lifted components securely before putting hands or feet under or working underneath any lifted component to prevent crushing injury or death from sudden dropping or inadvertent operation of controls. Make certain area is clear before lowering or folding.

5. Before transporting, put Lift Lever in detent or full-lift position. Install Transport Safety Devices securely on folding mowers. Put Booms securely in Transport Rest.





- Folding and Boom Mowers have raised center of gravity. Slow down when turning and on hillsides.

6. Make certain that SMV sign, warning lights, and reflectors are clearly visible. Follow local traffic codes.

7. Never operate with Cutting Head or Folding Section raised if passersby, bystanders, or traffic are in the area to reduce possibility of injury or death from objects thrown by Blades under Guards or mower structure.

8. Before dismounting, secure implement in transport position or lower to ground.

- Put tractor in park position or set brake, disengage PTO, stop engine, remove key, and wait until noise of rotation has ceased to prevent crushing by entanglement in rotating parts which could cause injury or death.
- Never mount or dismount a moving vehicle. Crushing from runover may cause serious injury or death.

<p>5. TRANSPORT SAFELY, LOCK UP.</p> 	<p>6. USE SMV, LIGHTS, &amp; REFLECTORS.</p> 	<p>7. DO NOT OPERATE WITH CUTTER OR WING RAISED</p> 	<p>8. DO NOT MOUNT OR DISMOUNT WHILE MOVING.</p> 
--	--	--	--

02967827



### WARNING

**Cancer and Reproductive Harm**  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

#### WARRANTY INFORMATION:

Read and understand the complete Warranty Statement found in this Manual. Fill out the Warranty Registration Form in full and return it to within 30 Days. Make certain the Serial Number of the Machine is recorded on the Warranty Card and on the Warranty Form that you retain.



# LIMITED WARRANTY



Bush Hog warrants to the original purchaser of any new Bush Hog equipment, purchased from an authorized Bush Hog dealer, that the equipment be free from defects in material and workmanship for a period of one (1) year for non-commercial, state and municipalities' use and ninety (90) days for commercial use from date of retail sale. The obligation of Bush Hog to the purchaser under this warranty is limited to the repair or replacement of defective parts.

Replacement or repair parts installed in the equipment covered by this limited warranty are warranted for ninety (90) days from the date of purchase of such part or to the expiration of the applicable new equipment warranty period, whichever occurs later. Warranted parts shall be provided at no cost to the user at an authorized Bush Hog dealer during regular working hours. Bush Hog reserves the right to inspect any equipment or parts which are claimed to have been defective in material or workmanship.

## DISCLAIMER OF IMPLIED WARRANTIES & CONSEQUENTIAL DAMAGES

Bush Hog's obligation under this limited warranty, to the extent allowed by law, is in lieu of all warranties, implied or expressed, **INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE** and any liability for incidental and consequential damages with respect to the sale or use of the items warranted. Such incidental and consequential damages shall include but not be limited to: transportation charges other than normal freight charges; cost of installation other than cost approved by Bush Hog; duty; taxes; charges for normal service or adjustment; loss of crops or any other loss of income; rental of substitute equipment, expenses due to loss, damage, detention or delay in the delivery of equipment or parts resulting from acts beyond the control of Bush Hog.

### THIS LIMITED WARRANTY SHALL NOT APPLY:

1. To vendor items which carry their own warranties, such as engines, tires, and tubes.
2. If the unit has been subjected to misapplication, abuse, misuse, negligence, fire or other accident.
3. If parts not made or supplied by Bush Hog have been used in connection with the unit, if, in the sole judgement of Bush Hog such use affects its performance, stability or reliability.
4. If the unit has been altered or repaired outside of an authorized Bush Hog dealership in a manner which, in the sole judgement of Bush Hog, affects its performance, stability or reliability.
5. To normal maintenance service and normal replacement items such as gearbox lubricant, hydraulic fluid, worn blades, or to normal deterioration of such things as belts and exterior finish due to use or exposure.
6. To expendable or wear items such as teeth, chains, sprockets, belts, springs and any other items that in the company's sole judgement is a wear item.

NO EMPLOYEE OR REPRESENTATIVE OF BUSH HOG IS AUTHORIZED TO CHANGE THIS LIMITED WARRANTY IN ANY WAY OR GRANT ANY OTHER WARRANTY UNLESS SUCH CHANGE IS MADE IN WRITING AND SIGNED BY BUSH HOG'S SERVICE MANAGER, 2501 GRIFFIN AVE., SELMA, ALABAMA 36703.



Record the model number, serial number and date purchased. This information will be helpful to your dealer if parts or service are required.

MODEL NUMBER \_\_\_\_\_

SERIAL NUMBER \_\_\_\_\_

DATE OF RETAIL SALE \_\_\_\_\_


MAKE CERTAIN THE WARRANTY HAS BEEN FILED WITH BUSH HOG SELMA, ALABAMA

**TABLE OF CONTENTS**  
**CROWNING GRADER, SKID STEER**  
**MODEL BHCG84**



Crowning Grader, 84" Skid Steer.....64-1-1, 64-1-2  
3-Point Hitch Kit (Optional).....64-2-1

# CROWNING GRADER 84" SKID STEER BHCG84



64-1-1


# CROWNING GRADER 84" SKID STEER BHCG84

Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.
1	-----	Frame Weldment	1	28	44621BH	Sratd Hex Flange Nut 3/8-16 G5 CP	4
2	BH1032300	Skid Bar Weldment, 56.5" - BH Red	2	29	1141006	Hex Bolt, 5/16-18 x .75"	2
3	BH1032270	Grader Blade Weldment, 84" BH Red	1	30	50072441	Nylock Nut, 5/16"	2
4	BH1023240	Cutting Edge, 84" Black	1	31	BH1006330	Sratd Hex Flange Bolt 3/8-16 x .75"	4
5	BH1032290	Jack, Sidewind	1	32	50035829	Owners Manual Tube	1
6	BH1024430	Model Number Decal, BHCG84	2	33	BH1027680	#6-7 x 1/4" RD HD U-Drive Screw ZP	8
7	BH1032140	Crown Indicator Left - BH Red	1	34	BH1032260	3/4-10 Castle Nut Med. Strength ZP	1
8	BH1023100	Hydraulic Cylinder - 2" x 6"	1	35	BH1003720	Cotter Pin 5/32" x 1-3/4"	1
9	BH1023250	Shank, 3/4" x 2.5" x 18" With HT Point	13	36	BH1014980	4MJ-6MB90 Adapter	1
10	BH1032310	Hitch Pin 5/8" x 2" & Clip	13	37	BH1031890	4MJ-6MB Orifice Adapter, 0.062"	1
11	BH1024380	Anti-Slip Tape	2	38	BH1023940	Cyl. Stroke Control Spacer, 1.125" x 1.5"	1
12	50083390	Bush Hog Decal, 4.52" x 29.00"	2	39	BH1023920	Grader Skid Steer Hose, 6'	2
13	BH1032110	Left Slider Bracket - BH Red	1	40	BH1017110	Male Flat Face End, A13 1/2 NPT	1
14	15921	Flatwasher, 3/4" SAE ZP	1	41	BH1017120	Female Flat Face End, 12A 1/2 NPT	1
15	5161610	Carriage Bolt, 1/2" x 1" G5 ZP	14	42	BH1024000	1/4" Hose Clamp Body	2
16	44615BH	Sratd Hex Flange Nut, 1/2-13 G5 CP	14	43	BH1008810	Cover Plate, 2D Group	1
17	20202	Hex Bolt 3/4-10 x 2" G5 ZP	2	44	BH1008790	Hex Bolt 5/16-18 x 1.375" G5 ZP	1
18	BH1024120	Locknut, 3/4-10, Two-Way Reversible	2	45	50084221	Operators Manual	1
19	50020915	Sq. Neck Flt. HD Plow Bolt 5/8" x 2"	9	46	D1173	Decal, Warning, Operation Hazards	1
20	BH1010790	Extra Duty Spring Lockwasher, 5/8" ZP	9	47	D623	Decal, Warning - Pinch Points	2
21	15563	Hex Nut, 5/8-11 ZP	9	48	D1172	Decal, Warning - Injection Hazard	1
22	BH1007480	#12 x 7/8" Driller Screw	3	49	BH1030100	Decal, Made in the USA	1
23	BH1032160	Right Indicator Plate - BH Red	1	50	-----	Serial No. Plate, BHCG84	1
24	BH1032180	SS Left Back Indicator Plate	1	51	D1174	Decal, Warning - Operation Hazards	1
25	BH1032190	SS Left Front Indicator Plate	1	52	00725746	Decal, Peligro	1
26	BH1032170	Indicator Right - BH Red	1	53	-----	Decal, P65 Warnings.ca.gov	1
27	44109BH	Carriage Bolt, 3/8" x 1" G5 ZP	2				





# 3-POINT HITCH KIT (OPTIONAL)



Item No.	Part No.	Description	Qty.
1	BH1023390	Lift Arm Pin, Forged, CAT 1 w/ LW & Nut	2
1A	63765	Lift Arm Pin, Forged, CAT 1	2
1B	44061BH	Hex Nut 7/8" NF Cp Class 2B	2
1C	15824	Lockwasher, 7/8" CP	1
2	BH1032150	Quick Hitch Spacer - BH Red	2
3	BH1032120	Left 3-Point Plate - BH Red	1
4	BH1032130	Right 3-Point Plate - BH Red	1
5	BH1033530	Hex Bolt 3/4"-10 x 4.25" Grade 5	2
6	45321BH	3/4" Nylock Nut	2
7	BH1006850	5/16" Lynch Pin	2
8	44094BH	Hex Bolt 1/2"-13 x 1.25"	6
9	44615BH	Sratd Hex Flange Nut 1/2-13 ZP	6
10	BH1023990	Lift Arm Bushing, 1-1/8" OD x 7/8" ID x 1-3/4" L	2
11	15916	Type A Flatwasher, 1/2"	6
12	BH1024040	Grader Hose, 3-Point Hitch	2
13	BH1015840	Male Pioneer End, 1/2 NPT	2
14	BH1017110	Male Flat Face End, A13 1/2 NPT	1
15	BH1017120	Female Flat Face End, 12A 1/2 NPT	1







**BUSH HOG®**

2501 Griffin Ave.  
Selma, AL. 36703